






This model of E-Coder has a light sensor that is recessed under the small round hole near the center of the dial face. The light sensor activates the LCD display for several minutes when exposed to a light source.

	<p>FLOW INDICATOR Shows the direction of flow through the meter:</p> <p>ON Water in use OFF Water not in use Flashing Water is running slowly / low flow indicator</p>
	<p>LEAK INDICATOR Displays a possible leak:</p> <p>OFF No leak indicated Flashing Intermittent leak indicates that water has been used for at least 50 of the 96 15-minute intervals during the previous 24-hour period. On Continuously Indicates water use for all 96 15-minute intervals during the previous 24-hour period.</p>
	<p>LCD DISPLAY Nine-digit LCD displays the meter reading in billing units of measure.</p> <p>1 Typical billing digits 2 Reading digits 3 Testing units used for meter testing</p>